

HG.::

~293 -295298 .215 .291 .220 .292 294 .296 -297 ALTERNATIVE PLAYBACK NUMBER 210 .214 .219 PLAYBACK PATH INFORMATION TABLE NEXT PLAYBACK NUMBER PLAYBACK CONTROL INFORMATION CONTENT NAME `Opening.mpg Interview.mpg · Trailer.mpg Purchase.mpg 221 Warning.mpg Trailer.mpg Menu.mpg Movie.mpg 213 218 PLAYBACK NUMBER




FIG. 5

**BUTTON DATA TABLE** 

249 SELECTED | GRAYED-OUT DATA PLAY PLAY 248 DATA PLAY PLAY PLAY 247 PURCHASE PLAY PLAY PLAY RIGHT BUTTON NUMBER ന 4 **BUTTON DATA** LEFT BUTTON NUMBER 2 ന LOWER BUTTON NUMBER -245 2 ന 4 UPPER BUTTON NUMBER 4 2  $\mathfrak{C}$ PLAYBACK NUMBER 242/2 ന  $\infty$ / BUTTON NUMBER 2  $^{\circ}$ 4 5/21

FIG.6




FIG.7




FIG. 8

			7266		_272		.273	)	_274	
KEY CONTROL INFORMATION TABLE ~ 260	2 Zé3 KEY CONTROL INFORMATION ZÉ5 ZZO	RIGHTS MODE INFORMATION	(-) 00	(-) 00	01 (MODE A)	(-) 00	(-) 00	01,10 (MODES A AND B)	10 (MODE B)	
		COPYABILITY   INFORMATION	01 (Once)	10 (Free)	00 (Never)	00 (Never)	00 (Never)	00 (Never)	00 (Never)	
		PLAYABILITY INFORMATION	(PLAYABLE)	1 (PLAYABLE)	0 (UNPLAYABLE)	1 (PLAYABLE)	1 (PLAYABLE)	0 (UNPLAYABLE)	0 (UNPLAYABLE)	7
		KEY GENERATION INFORMATION	(MEDIA KEY)	00 (MEDIA KEY)	O1 (COMPOSITE KEY)	00 (MEDIA KEY)	00 (MEDIA KEY)	10 / (RIGHTS KEY)	10 (RIGHTS KEY)	, 268 269
		CONTENT	1111	2222	3333	4444	5555	9999	7777	267 2
	Z9Z	CONTENT	Opening.mpg	Trailer.mpg	Movie.mpg	Warning.mpg	Menu.mpg	Making.mpg	Interview.mpg	
8/21										

FIG. 9


## MEDIA INFORMATION TABLE


<sub>₹</sub> 280


	MEDIA INFORMATION						
	DEVICE INFORMATION	ENCRYPTED MEDIA KEY					
281~	0001	qwerty	- 282				
	0002	asdfgh					
	0004	zxcvbn					
	0005	uiop@[					
	0006	jkl;:]					
	0007	m,./¥¥					
	:	:					


FIG. 10


RIGHTS INFORMATION TABLE


























FIG. 20

